

# CH37X USB MACOS DRIVER

## INSTALLATION INSTRUCTION

Version: V1A

<http://wch.cn>

### Introduction

This installation guide document shows the procedure for installing the macOS driver for part of WCH USB devices. The driver can be downloaded from the website:

Link: [http://www.wch.cn/downloads/CH37X\\_MAC\\_ZIP.html](http://www.wch.cn/downloads/CH37X_MAC_ZIP.html)

### System Requirement

- OS X 11.0(Big Sur) and above

### Chip Model Support

- CH372/CH374/CH375/CH376/CH378

### Installation

1. Download the driver from the website and unzip the file to a local installation directory.
2. Click on the driver file and drag “CH37xUSBDriver” to Application Folder.
3. Open “LaunchPad” and find “CH37xUSBDriver” Application, open the App and click the “Install ” button.
4. Open “Terminal” program under Applications-Utilities folder and type the command:  
“systemextensionsctl list”. If the state shows [activated enable], indicates that the driver installation was successful.

```
--- com.apple.system_extension.driver_extension
enabled active teamID bundleID (version) name [state]
* * 5JZGQTGU4W cn.wch.CH37xUSBDriver (1.0/1)
cn.wch.CH37xUSBDriver [activated enable]
```




**Note:**

macOS High Sierra 10.13 introduces a new feature that requires user's approval before loading new third-party kernel extensions.

Link: [https://developer.apple.com/library/content/technotes/tn2459/\\_index.html](https://developer.apple.com/library/content/technotes/tn2459/_index.html)

Please forward to "System Preferences"->"Security & Privacy"->"General" page, below the title "Allow apps downloaded from:" choose the choice 2->"Mac App Store and identified developers" so that driver will work normally.



## Uninstall Driver

- OS X 11.0 and above
1. Remove the Application to "Trash" to uninstall.
  2. Restart the computer before reinstalling the driver.