





# POWER



# LED




# USB





# MCU


## CH32F103C\_MINI




# XTAL




# BOOT




# PIN




# RST




# XTAL




# BOOT




# RST



# EEPROM




# CAN




# MCU

## CH32F103C\_EVT




# POWER




# TOUCHKEY


平面按键 (大圆盘)




# SWD




# LED




# PIN




# TF CARD




# UART




若使用232, 则用跳冒连接3-4、5-6




# SPI FLASH




# USB




# POWER



# LED




# USB




# MCU


## CH32F103R\_MINI




# XTAL



# BOOT



# RST



# PIN

